

A Step-by-Step Guide


1



Inspect & Clean the Container Exterior

- Check for rust, dents, and wear.
- Clean off dirt, grime, and rust spots.

2



Inspect & Clean the Container Exterior

- Inspect door gaskets for damage.
- Clean seals and apply lubricant so they stay watertight and functional.

3



Ensure Proper Ventilation

- Prevent condensation and moisture buildup inside container.
- Make sure vent holes are clear and unobstructed.

4



Interior Maintenance

- Clean the interior walls and floors.
- Consider renting shelving or organizational units for better storage.
- Evenly distribute contents to balance the container.

5



Electrical & Climate Control Systems

- Ensure necessary equipment is properly connected to power sources.
- Verify that the light bulbs are functional.
- Confirm that the circuit breakers have not been triggered.
- Clean or replace filters in your heating/air units (monthly).

6



Pest Control

- Regularly check for signs of pests.
- Keep the area around your container clear of debris and standing water.

7



Roof & Drainage Check

- Ensure the roof is free from pooling water.
- Check and clear drainage paths to prevent leaks and interior water damage.

With these simple steps, your shipping container is ready for another season! Regular maintenance ensures longevity and functionality.



Start your spring container maintenance today! For more tips and information, visit mobilemodularcontainers.com